

REVIT CATALOGUE READ ME

This catalogue contains important background data embedded within the Revit families, which should be reviewed to ensure key product information is not overlooked. Follow the scheduling setup instructions to ensure all catalogue products and associated data are captured within project schedules.

Disclaimer

Boss Passive Fire accepts no responsibility for any loss, damage, or consequence arising from the user editing or modifying parameters, dimensions, information, or other data in the Revit families that is critical to the product.

Generic Notes (all families)

A minimum 40mm gap is required between each FyreBox. The 40mm dimension must be taken from the edge of the aperture or the angle fixing brackets, whichever is greater.

Wall Mount Fyrebox Notes

Mid-Wall Mount: Install FyreBox with a recommended 10mm annular gap around the entire perimeter. Gaps up to 20mm may be permitted for some applications - consult the Technical Support Team.

Head-of-Wall / Soffit Mount: Install FyreBox flush to the soffit. A 10mm gap each side & below the FyreBox is recommended, with gaps up to 20mm permitted where applicable - consult the Technical Support Team.

Floor Mount Fyrebox Notes

Install FyreBox with a recommended 10mm annular gap around the entire perimeter. Gaps up to 20mm may be permitted for some applications - consult the Technical Support Team.

Wall Mount MaxiCollars

On/off parameters are built into the family that adds a matching collar instance to the back side of the wall when required. Consult the Technical Support Team to confirm specific requirements.

Cast-In Fyreboxes

On/off parameters are built into the family that adds the associated extension where required. Consult the Technical Support Team to confirm specific requirements.

Scheduling

1. New Schedule: Category - Generic Models. Schedule building components
2. Fields:
 - Product Code
 - Product Name
 - Product Type - Make 'Hidden field' under formatting (IMPORTANT)
 - Install Location
 - Level
 - Count
3. Filter by: Product Type - Parameter Exists (IMPORTANT)
4. Grouping & Sorting:
 - Sort by: Level (Header); Ascending.
 - Then by: Product Code; Ascending.
 - Then by: Product Name; Ascending.
 - Then by: Install Location; Ascending.
 - Grand Totals: Tick.
 - Itemize Every Instance: Do not tick.

